


FRONT FLOOR FOOTREST REPLACEMENT

76OOT-01



1. REMOVE FRONT FLOOR FOOTREST

- (a) Using a screwdriver, disengage 2 clips and remove the footrest.

HINT:

Tape the screwdriver tip before use.

2. INSTALL FRONT FLOOR FOOTREST

- (a) Install the footrest clips by engaging the claws with the footrest.

HINT:

Before the installation, check that the part of footrest to be engaged with the clips is not damaged.

NOTICE:

If it is damaged, replace it with a new one.