



REPLACEMENT

1. REMOVE REAR WHEEL




2. REMOVE SHOCK ABSORBER ASSY REAR LH

- (a) Support the rear axle housing.
- (b) Remove the bolt, separate the shock absorber assy rear LH from the rear axle housing.



- (c) Remove the nut, 3 cushion retainers, cushion No.1, cushion No.2 and shock absorber assy rear LH.




3. INSPECT SHOCK ABSORBER ASSY REAR LH

- (a) Compress and extend the shock absorber rod and check that there is no abnormal resistance or unusual sound during operation.

If there is any abnormality, replace the shock absorber with a new one.


NOTICE:

When disposing of the shock absorber, see **DISPOSAL** on page [27-5](#).




4. INSTALL SHOCK ABSORBER ASSY REAR LH

- (a) Install the 3 cushion retainer, cushion No.1, cushion No.2 and shock absorber assy rear LH with the nut.



- (b) Install the shock absorber assy rear LH with the bolt.




- (c) Fully tighten the nut.
Torque: 40 N·m (408 kgf·cm, 30 ft·lbf)

5. INSTALL REAR WHEEL

Torque: 112 N·m (1,137 kgf·cm, 83 ft·lbf)

6. STABILIZE SUSPENSION

- (a) Jack down the vehicle.
(b) Bounce the vehicle up and down several times to stabilize the suspension.



7. FULLY TIGHTEN SHOCK ABSORBER ASSY REAR LH

- (a) Fully tighten the bolt.
Torque: 98 N·m (1,000 kgf·cm, 72 ft·lbf)