



SEAT BELT WARNING LAMP FOR FRONT PASSENGER'S SEAT DOES NOT FLASH

WIRING DIAGRAM



INSPECTION PROCEDURE

1 INSPECT FRONT SEAT INNER BELT ASSY RH



- (a) Check the continuity.
 - (1) Short between terminals 1 and 3 of the occupant detection sensor connector.
 - (2) Check the continuity between terminals 1 and 2 of the front seat inner belt assy RH.


Standard:

Condition	Continuity
Seat belt is fastened	No continuity
Seat belt is unfastened	Continuity

NG → REPLACE FRONT SEAT INNER BELT ASSY RH

OK

2 CHECK COMBINATION METER ASSY



- (a) Remove the combination meter assy.
- (b) Check the continuity between terminal C9-13 of the combination meter connector and body ground.


Standard:

Condition	Continuity
Seat belt is fastened	Continuity
Seat belt is unfastened	No continuity

NG → REPAIR OR REPLACE COMBINATION METER ASSY

OK

3 INSPECT AIR CONDITIONING CONTROL ASSY



- (a) Check the passenger seat belt warning operation.
 - (1) Remove the air conditioning control assy with connector still connected.
 - (2) Ground terminal D3-3 (PBEW) of the air conditioning control assy.
 - (3) Check that the passenger seat belt warning light lights up.

Standard: Warning light lights up.

NG → REPAIR OR REPLACE AIR CONDITIONING CONTROL ASSY

OK

REPAIR OR REPLACE HARNESS OR CONNECTOR