


W/BOX SPEAKER ASSY NO.1 REPLACEMENT

670KZ-01

HINT:

COMPONENTS: See page 67-2

1. REMOVE TONNEAU COVER RETRACTOR SUB-ASSY(See page 76-42)
2. REMOVE BACK DOOR WEATHERSTRIP(See page 76-42)
3. REMOVE DECK BOARD SUB-ASSY(See page 76-42)
4. REMOVE DECK BOARD ASSY(See page 76-42)
5. REMOVE REAR FLOOR MAT SUPPORT PLATE REAR(See page 76-42)
6. REMOVE DECK FLOOR BOX RH(See page 76-42)
7. REMOVE DECK TRIM COVER REAR(See page 76-42)
8. REMOVE DECK TRIM SIDE BOARD UPR RH(See page 76-42)
9. REMOVE SIDE TRIM BOX ASSY RH(See page 76-42)
10. REMOVE REAR DOOR SCUFF PLATE RH(See page 76-42)
11. REMOVE REAR DOOR OPENING TRIM WEATHERSTRIP RH(See page 76-42)
12. REMOVE DECK TRIM SIDE PANEL ASSY RH(See page 76-42)
13. REMOVE ROOF SIDE GARNISH ASSY INNER RH(See page 76-42)



14. REMOVE W/BOX SPEAKER ASSY NO.1
 - (a) Disconnect the connectors.
 - (b) Remove the 5 bolts and w/box speaker assy No.1.