



# SEAT BELT WARNING LAMP FOR DRIVER'S SEAT DOES NOT OPERATE

## WIRING DIAGRAM



## INSPECTION PROCEDURE

### 1 CHECK COMBINATION METER ASSY



- Remove the combination meter assy.
- Check the continuity between terminal C9-12 of the combination meter connector and body ground.

#### Standard:


Condition	Continuity
Seat belt is fastened	Continuity
Seat belt is unfastened	No continuity

OK

**CHECK AND REPLACE COMBINATION METER ASSY**

NG

**2    INSPECT FRONT SEAT INNER BELT ASSY LH**



- (a) Check the resistance.
- (1) Check resistance between terminals 1 and 4 of the front seat inner belt assy LH.

**Standard:**

Condition	Resistance (Ω)
Seat belt is fastened	330
Seat belt is unfastened	1,330

**NG** **REPLACE FRONT SEAT INNER BELT ASSY LH**

**OK**

**REPAIR OR REPLACE HARNESS OR CONNECTOR**