

REPLACEMENT

HINT:

The installation is in the reverse order of the removal. However, when there is a special point concerning the installation, it is indicated.

1. REMOVE BACK DOOR SERVICE HOLE COVER LH (See page 75-39)

- (a) Remove the assist strap hole cover.
- (b) Remove the assist strap assy RH.
- (c) Remove the back door trim panel.
- (d) Remove the service hole cover LH.

2. REMOVE BACK DOOR GARNISH SUB-ASSY OUTSIDE

- (a) Remove the 6 nuts.
- (b) Disengage the 2 clips by pulling the garnish, and remove the garnish.