


# HEIGHT CONTROL DRYER ASSY REPLACEMENT

2501C-01

HINT:


COMPONENTS: See page 25-8

1. REMOVE REAR DISC WHEEL
2. REMOVE QUARTER PANEL MUDGUARD SUB-ASSY REAR LH
3. REMOVE REAR BUMPER (See page 76-6)
4. REMOVE FUEL TANK FILLER PIPE PROTECTOR (See page 25-1 1)
5. REMOVE SPARE DISC WHEEL
6. REMOVE HEIGHT CONTROL COMPRESSOR COVER (See page 25-1 1)
7. REMOVE HEIGHT CONTROL FILTER (See page 25-1 1)
8. DISCONNECT HEIGHT CONTROL TUBE NO.2 (See page 25-1 1)



## 9. REMOVE HEIGHT CONTROL DRYER ASSY

- (a) Disconnect the connector.
- (b) Remove the 3 bolts.



- (c) Remove the 3 bolts, the height control compressor and the dryer with the bracket.
- (d) Remove the bolt and the dryer.
- (e) Remove the O-ring.

## 10. INSTALL HEIGHT CONTROL DRYER ASSY

- (a) Install the bolt, the dryer and a new O-ring.  
**Torque: 6.4 N·m (65 kgf·cm, 57 in·lbf)**
- (b) Assemble the height control compressor, the dryer and the bracket as a unit to the vehicle, and tighten the 3 bolts to fix the bracket to the frame.  
**Torque: 29 N·m (300 kgf·cm, 21 ft·lbf)**
- (c) Install the height control compressor assy to the bracket with the 3 bolts.  
**Torque: 5.9 N·m (60 kgf·cm, 52 in·lbf)**
- (d) Connect the connector.
11. CONNECT HEIGHT CONTROL TUBE NO.2 (See page 25-1 1)
12. INSTALL HEIGHT CONTROL FILTER (See page 25-1 1)
13. INSTALL HEIGHT CONTROL COMPRESSOR COVER (See page 25-1 1)
14. INSPECT AIR LEAK (See page 25-3)
15. INSTALL SPARE DISC WHEEL
16. INSTALL FUEL TANK FILLER PIPE PROTECTOR (See page 25-1 1)

2003 4RUNNER REPAIR MANUAL (RM1001U)

17. **INSTALL REAR BUMPER (See page 76-6 )**
18. **INSTALL QUARTER PANEL MUDGUARD SUB-ASSY REAR LH**
19. **INSTALL REAR DISC WHEEL**  
Torque: 112 N·m (1,140 kgf·cm, 83 ft·lbf)