


CRANK POSITION SENSOR (2UZ-FE) REPLACEMENT

1805E-01

1. REMOVE ENGINE UNDER COVER ASSY REAR



2. REMOVE CRANK POSITION SENSOR

- (a) Disconnect the crank position sensor connector.
- (b) Remove the bolt and crankshaft position sensor.

3. INSTALL CRANK POSITION SENSOR

- (a) Install crank position sensor with bolt.
Torque: 6.5 N·m (65 kgf·cm, 58 in·lbf)

4. INSTALL ENGINE UNDER COVER ASSY REAR