




# VEHICLE LIFT AND SUPPORT LOCATIONS



**JACK POSITION** .....   
Front ..... Center of crossmember

Rear ..... Center of rear axle housing

**CAUTION:** When jacking up the front and rear, make sure the vehicle is not carrying any extra weight.

**SUPPORT POSITION**  
Safety stand .....   
Swing arm type lift ..... 