



SOUND QUALITY IS BAD IN ALL MODES (VOLUME IS TOO LOW)


WIRING DIAGRAM





H

I33768



H

I33769

INSPECTION PROCEDURE

1 ADJUST SOUND QUALITY

- (a) Adjust the sound quality.
 - (1) Operate the radio receiver assy to adjust the sound quality.

Standard: The condition returns to be normal.

OK → BAD SOUND QUALITY

NG

2 COMPARE IT WITH ANOTHER CAR OF SAME MODEL

- (a) Compare it with another vehicle of the same model.
 - (1) Compare with the vehicle of the same type which does not have a trouble to see if there is any difference in the condition of trouble occurrence.

Standard: No difference found.

OK → NORMAL

NG

3 INSPECT SYSTEM


- (a) Check the system.
 - (1) Check whether the stereo component amplifier assy is a built-in type or a separate type.

(A)	(B)
Built-in type amplifier	Separate type amplifier

B → Go to step 6

A

4 INSPECT RADIO RECEIVER ASSY (OUTPUT SIGNAL)



(a) Check that the voltage between terminals at each condition, as shown in the chart.

Standard:

Terminal	Condition	Specified condition
FL+/- ↔ GND	Audio system is sounding	A waveform synchronized with sounds is output
FR+/- ↔ GND	Audio system is sounding	A waveform synchronized with sounds is output
RL+/- ↔ GND	Audio system is sounding	A waveform synchronized with sounds is output
RR+/- ↔ GND	Audio system is sounding	A waveform synchronized with sounds is output

NG → **REPAIR OR REPLACE HARNESS OR CONNECTOR**

OK

5 CHECK SPEAKER (RESISTANCE)


(a) Check continuity.
 (1) Check that the continuity exists between terminals of speaker.
Standard: 2 - 8Ω

NG → **REPLACE SPEAKER**

OK

NORMAL

6 INSPECT RADIO RECEIVER ASSY (MUTE, GND)



(a) Check that the voltage between terminals at each condition, as shown in the chart.


Standard:

Terminal	Condition	Specified condition
MUTE ↔ GND	Audio system is sounding	3.5V or more

NG → **CHECK AND REPLACE RADIO RECEIVER ASSY**

OK

7 INSPECT STEREO COMPONENT AMPLIFIER ASSY (MUTE, GND)



(a) Check that the voltage between terminals at each condition, as shown in the chart.


Standard:

Terminal	Condition	Specified condition
MUTE ↔ GND	Audio system is sounding	3.5V or more

NG REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

8 INSPECT RADIO RECEIVER ASSY (OUTPUT SIGNAL)



(a) Check that the continuity between terminals at each condition, as shown in the chart.


Standard:

Terminal	Condition	Specified condition
R+/- ↔ GND	Audio system is sounding	A waveform synchronized with sounds is output
L+/- ↔ GND	Audio system is sounding	A waveform synchronized with sounds is output

NG CHECK AND REPLACE RADIO RECEIVER ASSY

OK

9 INSPECT STEREO COMPONENT AMPLIFIER ASSY (INPUT SIGNAL)



(a) Check that the continuity between terminals at each condition, as shown in the chart.


Standard:

Terminal	Condition	Specified condition
R+/- ↔ GND	Audio system is sounding	A waveform synchronized with sounds is output
L+/- ↔ GND	Audio system is sounding	A waveform synchronized with sounds is output

NG REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

10 INSPECT STEREO COMPONENT AMPLIFIER ASSY (OUTPUT SIGNAL)



(a) Check that the continuity between terminals at each condition, as shown in the chart.

Standard:

Terminal	Condition	Specified condition
FL+/- ↔ GND	Audio system is sounding	A waveform synchronized with sounds is output
FR+/- ↔ GND	Audio system is sounding	A waveform synchronized with sounds is output
RL+/- ↔ GND	Audio system is sounding	A waveform synchronized with sounds is output
RR+/- ↔ GND	Audio system is sounding	A waveform synchronized with sounds is output
WFL+/- ↔ GND	Audio system is sounding	A waveform synchronized with sounds is output
WFR+/- ↔ GND	Audio system is sounding	A waveform synchronized with sounds is output
CSP+/- ↔ GND	Audio system is sounding	A waveform synchronized with sounds is output
RS+/- ↔ GND	Audio system is sounding	A waveform synchronized with sounds is output

NG CHECK AND REPLACE STEREO COMPONENT AMPLIFIER ASSY

OK

11 CHECK SPEAKER (RESISTANCE)

- (a) Check continuity.
(1) Check that the continuity exists between terminals of speaker.
Standard: 2 - 8Ω

NG**REPLACE SPEAKER****OK****REPAIR OR REPLACE HARNESS OR CONNECTOR**