

DTC	P0121	THROTTLE/PEDAL POSITION SENSOR/SWITCH "A" CIRCUIT RANGE/PERFORMANCE PROBLEM
------------	--------------	--

CIRCUIT DESCRIPTION

Refer to DTC P0120 on page [05-51](#) .

HINT:

This is the procedure of the "throttle position sensor".

DTC No.	DTC Detection Condition	Trouble Area
P0121	Condition (a) continues for 2.0 seconds: (a) Difference between VTA1 and VTA2 is out of threshold	• Throttle position sensor (built in throttle body)

INSPECTION PROCEDURE

HINT:

Read freeze frame data using the hand-held tester or the OBD II scan tool, as freeze frame data records the engine conditions when a malfunction is detected. When troubleshooting, it is useful for determining whether the vehicle was running or stopped, the engine was warmed up or not, the air-fuel ratio was lean or rich, etc. at the time of the malfunction.

REPLACE THROTTLE W/MOTOR BODY ASSY (See page [10-6](#))