


REPLACEMENT

1. REMOVE REAR WHEEL

2. SEPARATE PARKING BRAKE CABLE ASSY NO.3

(a) Remove the bolt, separate the parking brake cable assy No.3.




3. REMOVE LOWER CONTROL ARM ASSY LH

(a) Remove the nut, washer and bolt from rear axle housing.

HINT:


While fixing the nut, turn and remove the bolt.



(b) Remove the nut, washer, bolt and the lower control arm assy.


HINT:


While fixing the nut, turn and remove the bolt.



4. INSTALL LOWER CONTROL ARM ASSY LH

(a) Install the lower control arm assy, temporarily tighten the nut, washer and bolt.





- (b) Install the rear axle housing, temporarily tighten the bolt, washer and nut.

5. CONNECT PARKING BRAKE CABLE ASSY NO.3


- (a) Connect the parking brake cable assy No.3 with the bolt.

Torque: 13 N·m (127 kgf·cm, 9 ft·lbf)

6. INSTALL REAR WHEEL

Torque: 112 N·m (1,137 kgf·cm, 83 ft·lbf)

- 7. STABILIZE SUSPENSION (See page 27-3)**



8. FULLY TIGHTEN LOWER CONTROL ARM ASSY LH

- (a) Fully tighten the 2 bolts.

Torque: 130 N·m (1,326 kgf·cm, 96 ft·lbf)

HINT:

While fixing the nut, turn and remove the bolt.