



ON-VEHICLE INSPECTION

1. CHECK SEAT HEATER CONTROL

- (a) Disconnect the connector from the seat heater control assy.
- (b) Check the voltage or continuity of each terminal of the wire harness side.

Standard:

Terminal No.	Condition	Specified Condition
6 ⇄ Body ground	Constant	Continuity
1 ⇄ 6	(Seat heater switch) OFF → ON	0 V → 10 - 14 V
4 ⇄ 6	Constant	10 - 14 V

If the result is not as specified, there may be a malfunction on the wire harness side or seat heater switch.