



## BLOWER MOTOR CIRCUIT

### Blower Level



$$\text{Duty Ratio} = \frac{A}{A + B} \times 100 (\%)$$




### CIRCUIT DESCRIPTION

The blower motor is operated by signals from the A/C amplifier. Blower motor speed signals are transmitted by changes in the Duty Ratio.

#### Duty Ratio

The duty ratio is the ratio of the period of continuity in one cycle. For example, if A is the period of continuity in one cycle, and B is the period of non-continuity, then.

### WIRING DIAGRAM



## INSPECTION PROCEDURE

### 1 PERFORM ACTUATOR CHECK

- Operate A/C control panel to enter the actuator check mode (See page 05-516 ).
- Press the blower switch and change to step operation.
- Check the air flow level by hand.

**Standard:**

Display Code	Blower level
0	0 (No blower)
1	1 (LO)
2	17 (Medium)
3	17 (Medium)
4	17 (Medium)
5	17 (Medium)
6	17 (Medium)
7	17 (Medium)
8	17 (Medium)
9	31 (HI)


OK

**PROCEED TO NEXT CIRCUIT INSPECTION  
SHOWN ON PROBLEM SYMPTOMS TABLE**

NG

### 2 CHECK FUSE(HTR NO.2)

Engine Room R/B:



- Remove the HTR No. 2 fuse from the engine room R/B.
- Check that the continuity exists in the HTR No. 2 fuse.


**Standard: Continuity exists.**

NG

**REPLACE FUSE**

OK

### 3 INSPECT BLOWER W/FAN MOTOR SUB-ASSY



- (a) Remove the blower w/ fan motor sub-assy.
- (b) Connect the battery positive (+) lead to terminal 2 and the battery negative (-) lead to terminal 1.

**Standard: Blower motor operates smoothly.**

**NG**

**REPLACE BLOWER W/FAN MOTOR SUB-ASSY**

**OK**

### 4 CHECK HARNESS AND CONNECTOR(BETWEEN HEATER BLOWER MOTOR RELAY AND BLOWER MOTOR CONTROL)

- (a) Check for open and short circuit in the harness and the connector between the blower motor relay and the blower motor control (See page [01-35](#) ).

**NG**

**REPAIR OR REPLACE HARNESS OR CONNECTOR**

**OK**

### 5 CHECK HARNESS AND CONNECTOR(BETWEEN BLOWER MOTOR CONTROL AND BODY GROUND)


- (a) Check for open and short circuit in the harness and the connector between the blower motor control and body ground (See page [01-35](#) ).

**NG**

**REPAIR OR REPLACE HARNESS OR CONNECTOR**

**OK**


## 6 INSPECT AIR CONDITIONING AMPLIFIER ASSY(BLW)



- Remove the A/C amplifier with the connectors being connected.
- Turn the ignition switch to ON.
- Set blower speed to LO.
- Check the waveform between terminal BLW of the A/C amplifier and body ground.

**Standard:**

The correct waveform appears as shown in the illustration.



**NG**

**CHECK AND REPLACE AIR CONDITIONING AMPLIFIER ASSY**

**OK**

## 7 CHECK HARNESS OR CONNECTOR(BETWEEN BLOWER MOTOR CONTROL AND AIR CONDITIONING AMPLIFIER)

- Check for open and short circuit in the harness and the connector between the blower motor control and the A/C amplifier (See page 01-35).

**NG**

**REPAIR OR REPLACE HARNESS OR CONNECTOR**

**OK**

**REPLACE BLOWER MOTOR CONTROL**