



## REPLACEMENT

### 1. REMOVE REAR WHEEL



### 2. SEPARATE SHOCK ABSORBER ASSY REAR LH

- (a) Support the rear axle housing.
- (b) Remove the bolt, separate the shock absorber assy rear LH from the rear axle.



### 3. DISCONNECT REAR BRAKE TUBE FLEXIBLE HOSE

- (a) Using SST, disconnect the 2 rear brake tubes from each of the flexible hoses.  
Use a container to catch brake fluid as it drains out.  
SST 09023-00100
- (b) Remove the 2 clips and disconnect the 2 flexible hoses.


### 4. REMOVE COIL SPRING REAR LH

- (a) Start to lower the rear axle housing.

#### NOTICE:

**Be careful not to snap the brake line and parking brake cable.**

- (b) While lowering the rear axle housing, remove the coil spring rear LH.




### 5. INSTALL COIL SPRING REAR LH

- (a) Install the coil spring rear LH to the rear axle housing.

#### HINT:


Fit the lower end of the coil spring into the gap of the spring lower seat.



### 6. CONNECT SHOCK ABSORBER ASSY REAR LH


- (a) Install the shock absorber, temporarily tighten the bolt.

## 7. STABILIZE SUSPENSION (See page 27-27 )



## 8. FULLY TIGHTEN SHOCK ABSORBER ASSY REAR LH

- (a) Fully tighten the bolt.  
**Torque: 98 N·m (1,000 kgf·cm, 72 ft·lbf)**



## 9. CONNECT REAR BRAKE TUBE FLEXIBLE HOSE

- (a) Install the 2 clips with the 2 flexible hoses.  
 (b) Using SST, connect the break tubes to the flexible hose.  
**Torque: 15 N·m (155 kgf·cm, 11 ft·lbf)**  
 SST 09023-00100

## 10. FILL RESERVOIR WITH BRAKE FLUID

## 11. BLEED BRAKE LINE (See page 32-4 )

## 12. CHECK FLUID LEVEL IN RESERVOIR (See page 32-4 )

## 13. CHECK BRAKE FLUID LEAKAGE

## 14. INSTALL REAR WHEEL

**Torque: 112 N·m (1,137 kgf·cm, 83 ft·lbf)**