


## REPLACEMENT

1. **PRECAUTION**(See page 60-1 )
  2. **DISCONNECT BATTERY NEGATIVE TERMINAL**(See page 60-1 )
  3. **REMOVE ROOF HEADLINING ASSY**(See page 76-42 )
  4. **REMOVE CURTAIN SHIELD AIR BAG ASSY LH**
    - (a) Using a screwdriver, disconnect the connector of the curtain shield airbag assy LH.
    - (b) Remove the 11 bolts and curtain shield airbag assy LH.
- HINT:**  
Remove the bolts from front side of the vehicle in order.



5. **INSPECT CURTAIN SHIELD AIR BAG ASSY LH**
  6. **INSTALL CURTAIN SHIELD AIR BAG ASSY LH**
    - (a) Install the curtain shield airbag assy LH with the 11 bolts.  
**Torque: 9.8 N·m (100 kgf·cm, 87 in.·lbf)**
- HINT:**  
Install the bolts from rear side of the vehicle in order.
- (b) Connect the curtain shield airbag assy LH connector.
  7. **INSTALL ROOF HEADLINING ASSY**(See page 76-42 )
  8. **INSPECT SRS WARNING LIGHT**(See page 05-614 )