


SUSPENSION CONTROL ECU REPLACEMENT

2501F-01

HINT:

COMPONENTS: See page 71-7

1. **DISCONNECT BATTERY NEGATIVE TERMINAL**
2. **INSTALL FRONT DOOR SCUFF PLATE LH**
3. **INSTALL COWL SIDE TRIM BOARD LH**
4. **REMOVE INSTRUMENT PANEL UNDER COVER SUB-ASSY NO.1 (See page 71-12)**
5. **REMOVE INSTRUMENT PANEL FINISH PLATE (See page 71-12)**
6. **REMOVE INSTRUMENT PANEL FINISH PANEL SUB-ASSY LOWER (See page 71-12)**
7. **REMOVE INSTRUMENT PANEL LOWER LH (See page 71-12)**



8. **REMOVE SUSPENSION CONTROL ECU**
 - (a) Disconnect the 3 suspension control ECU connectors.
 - (b) Remove the 2 bolts and the suspension control ECU.
9. **INSTALL SUSPENSION CONTROL ECU**
 - (a) Install the suspension control ECU with the 2 bolts.
Torque: 7.8 N·m (80 kgf·cm, 69 in.-lbf)
 - (b) Connect the 3 suspension control ECU connectors.

10. **INSTALL INSTRUMENT PANEL LOWER LH**
11. **INSTALL INSTRUMENT PANEL FINISH PANEL SUB-ASSY LOWER**
12. **INSTALL INSTRUMENT PANEL FINISH PLATE**
13. **INSTALL INSTRUMENT PANEL UNDER COVER SUB-ASSY NO.1**
14. **INSTALL COWL SIDE TRIM BOARD LH**
15. **INSTALL FRONT DOOR SCUFF PLATE LH**