

## PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See Page
All doors lock and unlock functions do not operate via master switch, driver side door key cylinder	<ol style="list-style-type: none"> <li>4. DOOR1 fuse</li> <li>5. ECU-B fuse</li> <li>6. Power window regulator master switch assy</li> <li>7. Front door lock assy LH</li> <li>8. Instrument panel junction block assy (body ECU)</li> <li>9. Wire harness</li> </ol>	<a href="#">05-1152</a>
Key lock-in prevention function does not work properly (Manual operation and operation interlocked with key are active)	<ol style="list-style-type: none"> <li>1. Unlock warning switch assy</li> <li>2. Courtesy lamp switch assy LH (Driver side door)</li> <li>3. Instrument panel junction block assy (body ECU)</li> <li>4. Wire harness</li> </ol>	<a href="#">05-1156</a>
Only back door can not be opened (Unlocked)	<ol style="list-style-type: none"> <li>1. Back door opener switch assy</li> <li>2. w/ Motor back door lock assy LH (Back door lock)</li> <li>3. Instrument panel junction block assy (body ECU)</li> <li>4. Wire harness</li> </ol>	<a href="#">05-1160</a>