


FUEL SUCTION W/PUMP & GAGE TUBE ASSY (2UZ-FE)

11015-01


Removal & Installation and Disassembly & Reassembly

1. REMOVE FUEL SUCTION W/PUMP & GAGE TUBE ASSY (See page 11-14)




2. REMOVE VAPOR PRESSURE SENSOR ASSY

- (a) Remove the tube joint clip, and pull out the vapor pressure sensor.



3. REMOVE FUEL SENDER GAGE ASSY

- (a) Disconnect the fuel sender gage connector.
- (b) Unlock the fuel sender gage, and slide it remove.



4. INSTALL VAPOR PRESSURE SENSOR ASSY

- (a) Install the vapor pressure sensor with the tube joint clip.

NOTICE:

- Check that there is no scratch or foreign objects on the connecting parts.
- Check that the fuel tube joint is inserted fully and securely.
- Check that the tube joint clip is on the collar of the fuel tube joint.
- After installing the tube joint clip, check that the fuel tube joint connector is not pulled off.

5. INSTALL FUEL SUCTION W/PUMP & GAGE TUBE ASSY (See page 11-14)