

<b>DTC</b>	<b>P0505</b>	<b>IDLE AIR CONTROL SYSTEM</b>
------------	--------------	--------------------------------

## CIRCUIT DESCRIPTION

The idle speed is controlled by the Electric Throttle Control System (ETCS).

ETCS is composed of the throttle motor to operate the throttle valve and the throttle position sensor to detect the opening angle of the throttle valve, the accelerator pedal position sensor to detect the accelerator pedal position, the ECM to control the ETCS, and the one valve type throttle body.

The ECM controls the throttle motor to make the throttle valve opening angle properly for the target idle speed.

DTC No.	DTC Detection Condition	Trouble Area
P0505	Idle speed continues to vary greatly from target speed (2 trip detection logic)	<ul style="list-style-type: none"> <li>• Electric throttle control system</li> <li>• Air induction system</li> <li>• PCV hose connection</li> <li>• ECM</li> </ul>

## INSPECTION PROCEDURE

### HINT:

Read freeze frame data using the hand-held tester or the OBD II scan tool, as freeze frame data records the engine conditions when a malfunction is detected. When troubleshooting, it is useful for determining whether the vehicle was running or stopped, the engine was warmed up or not, the air-fuel ratio was lean or rich, etc. at the time of the malfunction.

<b>1</b>	<b>CHECK OTHER DTC OUTPUT(BESIDES DTC P0505)</b>
----------	--

(a) Read the DTC using the hand-held tester or the OBD II scan tool.

### Result:

Display (DTC output)	Proceed to
Only P0505 is output	A
P0505 and other DTCs are output	B

### HINT:

If any other codes besides P0505 is output, perform the troubleshoot on that DTC before.

<b>B</b>	<b>GO TO RELEVANT DTC CHART (See page 05-18 )</b>
----------	---

<b>A</b>
----------

<b>2</b>	<b>CHECK CONNECTION OF PCV HOSE (See page 12-3 )</b>
----------	--

<b>NG</b>	<b>REPAIR OR REPLACE PCV HOSE</b>
-----------	-----------------------------------

<b>OK</b>
-----------

**3 CHECK AIR INDUCTION SYSTEM**

(a) Check the vacuum leaks in air induction system.

**NG****REPAIR OR REPLACE AIR INDUCTION SYSTEM****OK****CHECK ELECTRIC THROTTLE CONTROL SYSTEM (See page [10-1](#))**