


ADJUSTMENT

1. REMOVE REAR WHEEL
2. ADJUST PARKING BRAKE SHOE CLEARANCE (See page 33-15)
3. INSTALL REAR WHEEL
Torque: 103 N·m (1,050 kgf·cm, 76 ft·lbf)
4. INSPECT PARKING BRAKE PEDAL TRAVEL
 - (a) Slowly depress the parking brake pedal all the way, and count the number of clicks.
Parking brake pedal travel at 294 N (30 kgf, 66 lbf): 5 - 7 clicks



5. ADJUST PARKING BRAKE PEDAL TRAVEL
 - (a) Remove the console rear panel upper.
 - (b) Remove the console panel upper.
 - (c) Remove the rear console box.
 - (d) Confirm that the parking brake pedal is released.
 - (e) Loosen the lock nut and turn the adjusting nut until the parking brake pedal travel is corrected to the specification.
 - (f) Tighten the lock nut.
Torque: 13 N·m (127 kgf·cm, 9 ft·lbf)
 - (g) Check whether parking brake drags or not.
 - (h) When operating the parking brake pedal, check that the parking brake pedal indicator light comes on.
 - (i) Install the rear console box.
 - (j) Install the console panel upper.
 - (k) Install the console rear panel upper.