



## LICENSE PLATE LAMP BODY REPLACEMENT

1. REMOVE ASSIST STRAP HOLE COVER (See page 75-39 )
2. REMOVE ASSIST STRAP ASSY (See page 75-39 )
3. REMOVE BACK DOOR TRIM COVER (See page 75-39 )
4. REMOVE BACK DOOR TRIM BOARD (See page 75-39 )
5. REMOVE BACK DOOR GARNISH SUB-ASSY OUTSIDE (See page 76-38 )



### 6. REMOVE LICENSE PLATE LAMP ASSY


- (a) Loosen the 4 screws and remove the licence plate lamp assy.



### 7. REMOVE LICENSE PLATE LAMP LENS

- (a) Remove the 4 screws and 2 license plate lamp lenses.

### 8. REMOVE LICENSE PLATE LAMP LENS GASKET



### 9. REMOVE LICENSE PLATE LAMP BULB

- (a) Remove the 2 license plate lamp bulbs as shown in the illustration.

### 10. REMOVE LICENSE PLATE LAMP BODY