

TOUCH SWITCH DOES NOT FUNCTION (NAVIGATION SCREEN ONLY)

INSPECTION PROCEDURE

1 DISPLAY CHECK MODE(TOUCH SWITCH CHECK)

- (a) Perform display touch switch check of display check mode.
- (1) Start up the diagnosis system and perform display touch switch check of display check mode.
- STANDARD: Touch switch is normal**

NG

CHECK AND REPLACE RADIO RECEIVER ASSY

OK

2 CHECK SWITCH(BEEP SOUND)

- (a) Check the switch(Beep sound).
- (1) Press each touch switch on the navigation screen to check that the beep sounds are produced.
- STANDARD: Beep sound is normal**

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

CHECK AND REPLACE NAVIGATION ECU