

PROBLEM SYMPTOMS TABLE

Symptoms	Suspected Part	See Page
AUTO UP/DOWN function does not operate	<ol style="list-style-type: none"> 1. Power window regulator motor assy LH (Driver side) 2. Wire harness 3. Power window regulator master switch assy 	05-1099
Remote UP/DOWN function does not operate	<ol style="list-style-type: none"> 1. Power window regulator motor assy LH (Driver side) 2. Power window regulator master switch assy 3. Wire harness 	05-1102
Manual UP/DOWN function does not operate (Driver side)	<ol style="list-style-type: none"> 1. Power window regulator master switch assy 2. Power window regulator motor assy LH (Driver side) 3. Wire harness 	05-1105
Manual UP/DOWN function does not operate (Passenger side)	<ol style="list-style-type: none"> 1. Power window regulator switch assy (Passenger side) 2. Power window regulator motor assy RH (Passenger side) 3. Wire harness 	05-1107
Manual UP/DOWN function does not operate (Rear LH)	<ol style="list-style-type: none"> 1. Power window regulator switch assy rear (Rear LH) 2. Power window regulator motor assy LH (Rear LH) 3. Wire harness 	05-1110
Manual UP/DOWN function does not operate (Rear RH)	<ol style="list-style-type: none"> 1. Power window regulator switch assy rear (Rear RH) 2. Power window regulator motor assy RH (Rear RH) 3. Wire harness 	05-1113
Power windows do not operate at all	<ol style="list-style-type: none"> 1. POWER fuse 2. Power window relay 3. Power window regulator master switch assy 4. Wire harness 5. Instrument panel J/B assy 	05-1116
Door glass goes down during AUTO UP operation	<ol style="list-style-type: none"> 1. Front door glass run LH 2. Front door window glass LH 3. Front door window regulator sub-assy LH 	05-1119