


REPLACEMENT

1. PRECAUTION(See page 60-1)
2. DISCONNECT BATTERY NEGATIVE TERMINAL(See page 60-1)
3. REMOVE TONNEAU COVER RETRACTOR SUB-ASSY(See page 76-42)
4. REMOVE DECK BOARD ASSY(See page 76-42)
5. REMOVE REAR FLOOR MAT SUPPORT PLATE REAR(See page 76-42)
6. REMOVE DECK FLOOR BOX LH(See page 76-42)
7. REMOVE REAR DOOR SCUFF PLATE LH(See page 76-42)
8. REMOVE REAR DOOR OPENING TRIM WEATHERSTRIP LH(See page 76-42)
9. REMOVE LAP BELT OUTER ANCHOR COVER REAR NO.1 SAET(See page 76-42)
10. REMOVE DECK TRIM SIDE BOARD UPR LH(See page 76-42)
11. REMOVE PANEL ASSY, DECK TRIM SIDE, LH(See page 76-42)



12. REMOVE AIR BAG SENSOR REAR LH

- (a) Disconnect the connector of the airbag sensor rear LH.
- (b) Remove the 2 nuts and the airbag sensor rear LH.

13. INSTALL AIR BAG SENSOR REAR LH

- (a) Install the airbag sensor rear LH with the 2 nuts.
Torque: 17.5 N·m (178 kgf·cm, 13 ft·lbf)
- (b) Connect the connector of the airbag sensor rear LH.

NOTICE:

- Installation of the connector is done with the sensor assembly installed. Make sure the sensor assembly is installed with the specified torque.
 - If the sensor assembly has been dropped, or there are cracks, dents or other defects in the case, bracket or connector, replace the sensor assembly with a new one.
 - When installing the sensor assembly, take care that the SRS wiring does not interfere with other parts and is not pinched between other parts.
 - After installation, shake the sensor assembly to check that there is no looseness.
14. INSPECT AIR BAG SENSOR REAR LH(See page 60-8)
 15. INSPECT SRS WARNING LIGHT(See page 05-614)