

PROBLEM SYMPTOMS TABLE

Symptoms	Suspected Part	See Page
AUTO UP/DOWN function does not operate	1. Power window regulator motor assy LH (Back door) 2. Wire harness	05-1133
Door glass goes down during AUTO UP operation	1. Back door glass run 2. Back door power window regulator sub-assy 3. Back door glass	05-1135
Manual UP/DOWN function does not operate	1. Rear wiper motor assy 2. Power window regulator motor assy LH (Back door) 3. Wire harness 4. Multiplex network door ECU back (Back door ECU)	05-1136
Manual UP/DOWN function via back door lock key cylinder does not operate	1. Back door lock cylinder assy 2. Wire harness 3. Multiplex network door ECU back (Back door ECU)	05-1139