


## HEIGHT CONTROL INDICATOR LAMP CIRCUIT

### CIRCUIT DESCRIPTION

The height control indicator lamp indicates the aimed height, not the actual height.

It blinks when the height control is in operation by pressing the height control switch and stays on when the operation is completed.

## WIRING DIAGRAM



C

F43238

**INSPECTION PROCEDURE****1 INSPECT HEIGHT CONTROL INDICATOR LAMP**

HINT:

See combination meter troubleshooting on page [71-1](#) .**NG****REPAIR OR REPLACE BULB OR COMBINATION  
METER ASSEMBLY****OK****2 CHECK HARNESS AND CONNECTOR(SUSPENSION CONTROL ECU -  
COMBINATION METER ASSY)**

- (a) Check for open and short circuit in the harness and the connector between the suspension control ECU and the combination meter assy (height control indicator lamp) (See page [01-35](#) ).

**NG****REPAIR OR REPLACE HARNESS OR  
CONNECTOR****OK****CHECK AND REPLACE SUSPENSION CONTROL ECU (See page [01-35](#) )**