


PARK/NEUTRAL POSITION SWITCH ASSY REPLACEMENT

400UR-01

1. REMOVE COVER, ENGINE UNDER, NO.2
2. DISCONNECT PARK/NEUTRAL POSITION SWITCH CONNECTOR



3. REMOVE PARK/NEUTRAL POSITION SWITCH ASSY

- (a) Pry off the lock washer and remove the nut.
- (b) Remove the bolt and park/neutral position switch.

4. INSTALL PARK/NEUTRAL POSITION SWITCH ASSY

- (a) Install the park/neutral position switch with bolt.
Torque: 13 N·m (130 kgf·cm, 9 ft·lbf)
- (b) Install a new lock washer and nut.
Torque: 7 N·m (71 kgf·cm, 62 in·lbf)
- (c) Bent the claws on the lock washer to stake the nut.
- (d) Adjust the park/neutral position switch (See page [40-4](#)).

5. CONNECT PARK/NEUTRAL POSITION SWITCH CONNECTOR

6. INSTALL COVER, ENGINE UNDER, NO.2

7. INSPECT PARK/NEUTRAL POSITION SWITCH ASSY(See page [40-4](#))