


REAR AXLE LH HUB BOLT REPLACEMENT


300F9-01

1. REMOVE REAR WHEEL
2. REMOVE SPEED SENSOR REAR LH (See page 32-52)
3. SEPARATE REAR DISC BRAKE CALIPER ASSY LH (See page 32-23)
4. REMOVE REAR DISC
5. REMOVE PARKING BRAKE SHOE RETURN TENSION SPRING (See page 33-15)
6. REMOVE PARKING BRAKE SHOE STRUT COMPRESSION SPRING (See page 33-15)
7. REMOVE PARKING BRAKE SHOE STRUT LH (See page 33-15)
8. REMOVE PARKING BRAKE SHOE (See page 33-15)



9. REMOVE REAR AXLE LH HUB BOLT

- (a) Using SST, remove the hub bolt.
SST 09650-1701 1



10. INSTALL REAR AXLE LH HUB BOLT

- (a) Pass a new hub bolt through the axle hub.
- (b) Pass a washer plate, as shown in the illustration, through the hub bolt, and install the hub bolt as tightening the hub nut.

11. INSTALL PARKING BRAKE SHOE (See page 33-15)
12. INSTALL PARKING BRAKE SHOE STRUT LH (See page 33-15)
13. INSTALL PARKING BRAKE SHOE STRUT COMPRESSION SPRING (See page 33-15)
14. INSTALL PARKING BRAKE SHOE RETURN TENSION SPRING (See page 33-15)
15. INSTALL REAR DISC
16. CONNECT REAR DISC BRAKE CALIPER ASSY LH (See page 32-23)
17. INSTALL SPEED SENSOR REAR LH (See page 32-52)
18. FILL RESERVOIR WITH BRAKE FLUID (See page 32-4)
19. BLEED BRAKE LINE (See page 32-4)
20. INSPECT BRAKE FLUID LEVEL IN RESERVOIR (See page 32-4)
21. CHECK BRAKE FLUID LEAKAGE (See page 32-4)
22. INSTALL REAR WHEEL
Torque: 112 N·m (1,142 kgf·cm, 83 ft·lbf)
23. INSPECT AND ADJUST PARKING BRAKE LEVER TRAVEL (See page 33-2)
24. CHECK ABS SPEED SENSOR SIGNAL (See page 05-307)

2003 4RUNNER REPAIR MANUAL (RM1001U)