

PRE-CHECK

1. USING HAND-HELD TESTER

- (a) Hook up hand-held tester to the DLC3.
- (b) Monitor the ECU data by following the prompts on the tester screen.

HINT:

The hand-held tester has a "Snapshot" function which records the monitored data.

Refer to the hand-held tester operator's manual for further details.

2. DATA LIST

HINT:

According to the DATA LIST displayed by the hand-held tester, you can read the value of the switch, sensor, actuator and so on without parts removal. Reading the DATA LIST as a first step of troubleshooting is one of the method to shorten the labor time.

- (a) Connect the hand-held tester to the DLC3.
- (b) Turn the ignition switch ON.
- (c) According to the display on tester, read the DATA LIST.

Standard (Body ECU):

Item	Measurement Item/Display (Range)	Normal Condition	Diagnostic Note
KEY UNLK WRN SW	Key unlock warning SW signal/ ON or OFF	ON: Key is in IG key cylinder OFF: No key is in IG key cylinder	-
D DOOR CTY SW	Driver's door courtesy SW signal/ ON or OFF	ON: Driver's door is open OFF: Driver's door is closed	-