


# BACK DOOR DUMPER STAY SUB-ASSY LH

## REPLACEMENT

750IC-01

**HINT:**

On the RH side, use the same procedures as on the LH side.

**1. REMOVE BACK DOOR DUMPER STAY SUB-ASSY LH**

- (a) Remove the 2 bolt and damper stay from the door panel.

**HINT:**

While supporting the hood by hand, remove the hood support.

- (b) Loosen the bolt and remove the damper stay from the vehicle body.

**2. INSTALL BACK DOOR DUMPER STAY SUB-ASSY LH**

- (a) Install the damper stay with the 3 bolts.

**Torque:**

**19.5 N·m (200 kgf·cm, 14 ft·lbf) for door side**

**17.5 N·m (180 kgf·cm, 13 ft·lbf) for body side**