


TURNING ON LIGHT SWITCH DOES NOT LIGHT UP NIGHT TIME ILLUMINATION OF RADIO RECEIVER


WIRING DIAGRAM



INSPECTION PROCEDURE

1 INSPECT RADIO RECEIVER ASSY(ILL+B, GND)

6 Speaker (Built-in AMP):




- (a) Check that the voltage between terminals at each condition, as shown in the chart.

Standard:

Tester connection	Condition	Specified condition
ILL+B ↔ GND	Light control switch TAIL or HEAD	10 - 14 V

Except 6 Speaker (Separate AMP):




OK

CHECK AND REPLACE RADIO RECEIVER ASSY

NG

2 INSPECT RADIO RECEIVER ASSY(ILL-, GND)

6 Speaker (Built-in AMP):




- (a) Check that the voltage between terminals at each condition, as shown in the chart.

Standard:

Tester connection	Condition	Specified condition
ILL- ↔ GND	Light control switch TAIL or HEAD	Continuity

Except 6 Speaker (Separate AMP):



OK

CHECK AND REPLACE RADIO RECEIVER ASSY

NG

3	INSPECT LIGHT CONTROL RHEOSTAT(See Page71-6)
---	--

OK

CHECK AND REPLACE RADIO RECEIVER ASSY

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR
--