

HOW TO PROCEED WITH TROUBLESHOOTING

1 VEHICLE BROUGHT TO WORK SHOP




2 CUSTOMER PROBLEM ANALYSIS (See page 05-821)




3 CHECK BODY MULTIPLEX COMMUNICATION SYSTEM (See page 05-1268)

(a) Check that the DTC outputs.




DTC OUTPUTS (PROCEED TO "BODY MULTIPLEX COMMUNICATION SYSTEM")




DTC DOES NOT OUTPUT (GO TO STEP 4)

4 DTC CHECK (See Page 05-822)




MALFUNCTION CODE (GO TO STEP 5)



NORMAL CODE (GO TO STEP 6)

5 DTC CHART (See Page 05-825)



GO TO STEP 8

6 PROBLEM SYMPTOMS TABLE (See page 05-831)



7 TERMINAL OF ECU (See page 05-828)



8 CIRCUIT INSPECTION (See Page 05-833 - 05-858)



9 IDENTIFICATION OF PROBLEM



10 REPAIR OR REPLACE



11	CONFIRMATION TEST
----	-------------------



END
