



# TRANSMISSION CONTROL CABLE ASSY REPLACEMENT

400V2-01


1. REMOVE CONSOLE UPPER REAR PANEL SUB-ASSY
2. REMOVE CONSOLE PANEL SUB-ASSY UPPER
3. REMOVE CONSOLE UPPER PANEL GARNISH NO.1
4. REMOVE CONSOLE UPPER PANEL GARNISH NO.2
5. REMOVE CONSOLE BOX ASSY REAR
6. REMOVE TRANSMISSION CONTROL CABLE ASSY
  - (a) Disconnect the transmission control cable assy from shift lever assy.




- (b) Remove the lock plate and disconnect the transmission control cable.




- (c) Remove the 2 bolts and disconnect the transmission control cable assy from body.



- (d) Remove the 2 nuts and disconnect the transmission control cable assy from body.




- (e) Remove the lock plate and transmission control cable bracket.
- (f) Remove the nut and transmission control cable assy.




## 7. INSTALL TRANSMISSION CONTROL CABLE ASSY


- (a) Install the transmission control cable assy with the nut.  
**Torque: 12 N·m (122 kgf·cm, 9ft·lbf)**
- (b) Install the transmission control cable bracket and lock plate.



- (c) Connect the transmission control cable with the 2 nuts to body.



- (d) Connect the transmission control cable with the 2 bolts to body.



- (e) Connect the transmission control cable with the lock plate to floor shift assy.
- (f) Install the transmission control cable to floor shift assy.

8. INSTALL CONSOLE BOX ASSY REAR
9. INSTALL CONSOLE UPPER PANEL GARNISH NO.2
10. INSTALL CONSOLE UPPER PANEL GARNISH NO.1
11. INSTALL CONSOLE PANEL SUB-ASSY UPPER
12. INSTALL CONSOLE UPPER REAR PANEL SUB-ASSY