

PROBLEM SYMPTOMS TABLE

Symptom	Suspect Area	See page
Pressing power switch does not start system.	3. Radio receiver assy power source circuit 4. Radio receiver assy	05-905
Turning on light switch does not light up night time illumination of radio receiver.	1. Radio receiver assy ILL terminal circuit 2. Radio receiver assy	05-907
No sound is heard from speaker in all modes.	1. Speaker circuit 2. Radio receiver assy power source circuit 3. Radio receiver assy	05-910
Sound quality is bad in all modes. (Volume is too low)	1. Speaker circuit 2. Radio receiver assy power source circuit 3. Radio receiver assy	05-917
Radio broadcast cannot be received. (Bad reception)	1. Antenna circuit 2. Radio receiver assy	05-925
Cassette tape cannot be inserted or played.	1. Cassette tape 2. Radio receiver assy power source circuit 3. Radio receiver assy	05-927
Cassette tape cannot be ejected.	1. Cassette tape 2. Radio receiver assy power source circuit 3. Radio receiver assy	05-929
Sound quality is bad only when playing tape.	1. Cassette tape 2. Radio receiver assy	05-932
Tape is tangled due to incorrect tape speed or auto-reverse malfunction.	1. Cassette tape 2. Radio receiver assy	05-933
CD cannot be inserted or is ejected right after insertion.	1. CD 2. Radio receiver assy power source circuit 3. Radio receiver assy	05-934
Although system is powered, CD cannot be played.	1. CD 2. Radio receiver assy power source circuit 3. Radio receiver assy	05-937
CD cannot be taken out.	1. CD 2. Radio receiver assy power source circuit 3. Radio receiver assy	05-940
Sound quality is bad only when CD is played.(Volume is too low)	1. CD	05-942
CD sound skips.	1. CD 2. Radio installation	05-943
Noise occurs.	-	05-945
Quality of sound from wireless headphone is poor or no sound can be heard.	1. Battery 2. Radio receiver assy 3. Stereo component controller assy	05-946
Rear seat entertainment system does not respond to any remote control operations.	1. Battery 2. Radio receiver assy 3. Stereo component controller assy	05-951