

DTC	B1187/55	SHORT IN P SQUIB (2ND STEP) CIRCUIT (TO GROUND)
------------	-----------------	--

CIRCUIT DESCRIPTION

The P squib (2nd step) circuit consists of the airbag sensor assy center and the instr pnl pass l/door airbag assy.

It causes the SRS to deploy when the SRS deployment conditions are satisfied.

DTC B1187/55 is recorded when ground short is detected in the P squib (2nd step) circuit.


DTC No.	DTC Detecting Condition	Trouble Area
B1187/55	<ul style="list-style-type: none"> • Short in P squib (2nd step) circuit (to ground) • P squib (2nd step) malfunction • Airbag sensor assy center malfunction 	<ul style="list-style-type: none"> • Instr pnl pass l/door airbag assy (P squib, 2nd step) • Airbag sensor assy center • Instrument panel wire

WIRING DIAGRAM

See page 05-796 .

INSPECTION PROCEDURE

1	CHECK INSTRUMENT PANEL WIRE(P SQUIB (2ND STEP) CIRCUIT)
----------	--



- (a) Disconnect the negative (-) terminal cable from the battery, and wait at least for 90 seconds.
- (b) Disconnect the instrument panel wire connectors from the airbag sensor assy center and the instr pnl pass l/door airbag assy.
- (c) Measure the resistance between the body ground and P2+ of the orange instrument panel wire connector on the instr pnl pass l/door airbag assy side.

OK:


Resistance: 1 MΩ or Higher

NG	REPAIR OR REPLACE INSTRUMENT PANEL WIRE
-----------	--

OK

2 CHECK AIR BAG SENSOR ASSY CENTER

SST 09843-18040



- Connect the connector to the airbag sensor assy center.
- Using a service wire, connect P2+ and P2- of the orange instrument panel wire connector on the instr pnl pass l/ door airbag assy side.
- Connect the negative (-) terminal cable to the battery, and wait at least for 2 seconds.
- Turn the ignition switch to ON, and wait at least for 10 seconds.
- Clear the DTC stored in memory (See page 05-614).
- Turn the ignition switch to LOCK, and wait at least for 10 seconds.
- Turn the ignition switch to ON, and wait at least for 10 seconds.
- Check the DTC (See page 05-614).


OK:**DTC B1187/55 is not output.****HINT:**

Codes other than code B1187/55 may be output at this time, but they are not relevant to this check.

NG**REPLACE AIR BAG SENSOR ASSY CENTER****OK**

3 CHECK P SQUIB

SST 09843-18040



- (a) Turn the ignition switch to LOCK.
- (b) Disconnect the negative (-) terminal cable from the battery, and wait at least for 90 seconds.
- (c) Connect the instr pnl pass l/door airbag assy connectors.
- (d) Connect the negative (-) terminal cable to the battery, and wait at least for 2 seconds.
- (e) Turn the ignition switch to ON, and wait at least for 10 seconds.
- (f) Clear the DTC stored in memory (See page 05-614).
- (g) Turn the ignition switch to LOCK, and wait at least for 10 seconds.
- (h) Turn the ignition switch to ON, and wait at least for 10 seconds.
- (i) Check the DTC (See page 05-614).

OK:

DTC B1187/55 is not output.

HINT:

Codes other than code B1187/55 may be output at this time, but they are not relevant to this check.

NG → **REPLACE INSTR PNL PASS L/DOOR AIR BAG ASSY**

OK

4 USE SIMULATION METHOD TO CHECK

NG → **Go to step 1**

OK

REPLACE ALL SRS COMPONENTS INCLUDING WIRE HARNESS