

<b>DTC</b>	<b>B1149/37</b>	<b>FRONT AIRBAG SENSOR (LH) MALFUNCTION</b>
------------	-----------------	---


## CIRCUIT DESCRIPTION

The airbag sensor front LH circuit consists of a diagnosis circuit and a frontal deceleration sensor, etc. It receives signals from the frontal deceleration sensor, judges whether or not the SRS must be activated, and detects a diagnosis system malfunction.

DTC B1149/37 is recorded when malfunction is detected in the airbag sensor front LH circuit.

DTC No.	DTC Detecting Condition	Trouble Area
B1149/37	<ul style="list-style-type: none"> <li>• Open in airbag sensor front LH circuit</li> <li>• Airbag sensor front LH malfunction</li> <li>• Airbag sensor assy center malfunction</li> </ul>	<ul style="list-style-type: none"> <li>• Airbag sensor front LH</li> <li>• Airbag sensor assy center</li> <li>• Instrument panel wire</li> <li>• Engine room main wire</li> </ul>

## WIRING DIAGRAM




H16901

## INSPECTION PROCEDURE

## 1 CHECK AIR BAG SENSOR FRONT LH

SST 09843-18040



- Connect negative (-) terminal cable to the battery, and wait at least for 2 seconds.
- Turn the ignition switch to ON position, and wait at least for 10 seconds.
- Clear the DTC stored in the memory (See page 05-615 ).
- Turn the ignition switch to LOCK position, and wait at least for 10 seconds.
- Turn the ignition switch to ON position, and wait at least for 10 seconds.
- Check the DTC (See page 05-615 ).

**OK:****DTC B1149/37 is not output.****HINT:**

Codes other than code B1149/37 may be output at this time, but they are not relevant to this check.

**OK****USE SIMULATION METHOD TO CHECK****NG**

**2 CHECK AIRBAG SENSOR ASSY CENTER CONNECTOR**

- (a) Turn the ignition switch to LOCK position.
- (b) Disconnect the negative (-) terminal cable from the battery, and wait at least for 90 seconds.
- (c) Check that the connector is properly connected to the airbag sensor assy center.


**OK:****The connectors are connected.****NG****CONNECT CONNECTORS****OK****3 CHECK FRONT AIRBAG SENSOR CONNECTOR**

- (a) Check that the connector is properly connected to the airbag sensor front LH.

**OK:****The connector is connected.****NG****CONNECT CONNECTORS****OK**

#### 4 CHECK FRONT AIRBAG SENSOR (LH) CIRCUIT (OPEN)

SST 09843-18040




- Disconnect the connectors between the airbag sensor assy center and the airbag sensor front LH.
- Using a service wire, connect +SL and -SL of the connector on the airbag sensor front LH side between the airbag sensor assy center and the airbag sensor front LH.
- Measure the resistance between +SL and -SL of the connector on the airbag sensor assy center side between the airbag sensor assy center and the airbag sensor front LH.

**OK:****Resistance: Below 1  $\Omega$** **NG****Go to step 6****OK**

## 5 CHECK AIR BAG FRONT RH SENSOR

SST 09843-18040



- Turn the ignition switch to LOCK.
- Disconnect the negative (-) terminal cable from the battery, and wait at least for 90 seconds.
- Connect the airbag sensor assy center connector.
- Interchange the airbag front sensor RH with LH and connect the connectors to them.
- Connect the negative (-) terminal cable to the battery, and wait at least for 2 seconds.
- Turn the ignition switch to ON position, and wait at least for 10 seconds.
- Clear the DTC stored in the memory (See page 05-615 ).
- Turn the ignition switch to LOCK position, and wait at least for 10 seconds.
- Turn the ignition switch to ON position, and wait at least for 10 seconds.
- Check the DTC (See page 05-615 ).

**OK:****(A): DTC B1148/36 is not output.****(B): DTC B1149/37 is not output.**

**NG(A) > REPLACE AIR BAG SENSOR FRONT LH**


**NG(B) > REPLACE AIR BAG SENSOR ASSY CENTER**

**OK**

**USE SIMULATION METHOD TO CHECK**

## 6 CHECK ENGINE ROOM MAIN WIRE (OPEN)

SST 09843-18040



- Disconnect the engine room main wire connector from the instrument panel wire.
- Using a service wire, connect +SL and -SL of the engine room main wire connector on the airbag sensor front LH side.
- Measure the resistance between +SL and -SL of the engine room main wire connector on the airbag sensor assy center side.

**OK:****Resistance: Below 1  $\Omega$** **NG****REPAIR OR REPLACE ENGINE ROOM MAIN WIRE****OK****REPAIR OR REPLACE INSTRUMENT PANEL WIRE**

**-MEMO-**