




PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See Page
Tension reducer for driver side seat belt does not operate	1. GAUGE fuse 2. Front seat inner belt assy LH 3. Front seat outer belt assy LH 4. Wire harness	 61-3 61-3 
Tension reducer for passenger side seat belt does not operate	1. GAUGE fuse 2. Front seat inner belt assy RH 3. Front seat outer belt assy RH 4. Wire harness	 61-3 61-3 