



OVERHAUL

1. REMOVE CONSOLE UPPER REAR PANEL SUB-ASSY
2. REMOVE CONSOLE PANEL SUB-ASSY UPPER
3. REMOVE CONSOLE UPPER PANEL GARNISH NO.1
4. REMOVE CONSOLE UPPER PANEL GARNISH NO.2
5. REMOVE CONSOLE BOX ASSY REAR




6. REMOVE FLOOR SHIFT ASSY

- (a) Disconnect the 2 connectors and 2 clamps.
- (b) Remove the lock plate and disconnect the transmission control cable.
- (c) Remove the 4 bolts and floor shift assy.




7. REMOVE FLOOR SHIFT SHIFT LEVER KNOB SUB-ASSY

- (a) Remove the floor shift lever knob from the shift lever.




8. REMOVE POSITION INDICATOR HOUSING SUB-ASSY

- (a) Release the 4 claws with a screwdriver and remove the shift position indicator housing sub-assy and slide cover.




9. REMOVE LOWER POSITION INDICATOR HOUSING


- (a) Disconnect the 3 clamps of indicator lamp wire sub-assy.
- (b) Release the 4 claws with a screwdriver and remove the lower position indicator housing.

10. REMOVE SHIFT LOCK RELEASE BUTTON**11. REMOVE SHIFT LOCK RELEASE BUTTON COVER****12. REMOVE INDICATOR LAMP WIRE SUB-ASSY**


- (a) Remove the indicator lamp wire sub-assy.
- (b) Remove the bulb from the indicator lamp wire sub-assy.

**13. REMOVE SHIFT LEVER GUIDE HOUSING**

- (a) Remove the shift lever nut and shift lever lock pin.
- (b) Remove the shift lever guide housing.
- (c) Release the 2 claws with a screwdriver and remove the shift lock release link and spring.

**14. REMOVE SHIFT LOCK CONTROL ECU SUB-ASSY**

- (a) Remove the 2 screws and the shift lock control ECU.

**15. INSTALL SHIFT LOCK CONTROL ECU SUB-ASSY**


- (a) Install the shift lock control ECU with the 2 screws.

16. INSTALL SHIFT LEVER GUIDE HOUSING

- (a) Install the spring and shift lock release link.
- (b) Install the shift lever guide housing.
- (c) Install the lever lock and shift lever nut.

17. INSTALL INDICATOR LAMP WIRE SUB-ASSY


(a) Install the bulb to the indicator lamp wire sub-assy.



(b) Install the indicator lamp wire sub-assy.

18. INSTALL SHIFT LOCK RELEASE BUTTON COVER


19. INSTALL SHIFT LOCK RELEASE BUTTON



20. INSTALL LOWER POSITION INDICATOR HOUSING

(a) Install the lower position indicator housing.


(b) Connect the 3 clamps of indicator lamp wire sub-assy.



21. INSTALL POSITION INDICATOR HOUSING SUB-ASSY


(a) Install the slide cover and position indicator housing sub-assy to the shift lever guide housing.

HINT:
Firmly make the claws fit.



22. INSTALL FLOOR SHIFT SHIFT LEVER KNOB SUB-ASSY

(a) Install the floor shift lever knob to the shift lever.

**23. INSTALL FLOOR SHIFT ASSY**

- (a) Install the floor shift assy with the 4 bolts.
Torque: 12 N·m (122 kgf·cm, 9 ft·lbf)
- (b) Connect the transmission control cable with the lock plate.
- (c) Connect the 2 clamps and 2 connectors.

24. ADJUST SHIFT LEVER POSITION(See page 40-39)

25. INSTALL CONSOLE BOX ASSY REAR

26. INSTALL CONSOLE UPPER PANEL GARNISH NO.2

27. INSTALL CONSOLE UPPER PANEL GARNISH NO.1

28. INSTALL CONSOLE PANEL SUB-ASSY UPPER

29. INSTALL CONSOLE UPPER REAR PANEL SUB-ASSY

30. INSPECT SHIFT LEVER POSITION(See page 40-39)