


INNER REAR VIEW MIRROR ASSY REPLACEMENT


HINT:

The installation is in the reverse order of the removal.



1. REMOVE INNER REAR VIEW MIRROR ASSY

- (a) Pushing portions (a) as indicated in the illustration, remove the cover.
- (b) Pushing the claw in the direction (b), slide the mirror assy in the direction (c) to remove it.



2. REMOVE INNER REAR VIEW MIRROR ASSY (ELECTRO CHROMIC MIRROR INNER MIRROR)

- (a) Remove the mirror cover.
- (b) Disconnect the connector.
- (c) Remove the mirror assy as shown in the illustration.