


DTC	B2215	BACK DOOR CLOSER SWITCH MALFUNCTION
-----	-------	--

CIRCUIT DESCRIPTION

This DTC is output when the position switch in the back door malfunctions. This position switch detects the back door LOCK/UNLOCK and sends it to the back door ECU.


DTC No.	DTC Detection Condition	Trouble Area
B2215	Back door does not operate	<ul style="list-style-type: none">• w/ Motor back door lock assy (back door lock)• Multiplex network door ECU back (back door ECU)• Wire harness

WIRING DIAGRAM



INSPECTION PROCEDURE

1 CHECK WIRE HARNESS (W/MOTOR BACK DOOR LOCK ASSY (BACK DOOR LOCK) ⇔ MULTIPLEX NETWORK DOOR ECU BACK (BACK BODY ECU))



- (a) Disconnect the B7 back door lock and B9 back door ECU connectors.
- (b) Check the continuity between the terminals of the back door lock (B7) and back door ECU (B9) connectors.

Standard (Check for open) :


Symbols (Terminal No.)	Specified Condition
- (B7-4) ⇔ POS (B9-8)	Continuity
- (B7-3) ⇔ LSE (B9-21)	

NG REPAIR OR REPLACE HARNESS AND CONNECTOR

OK

2

INSPECT W/MOTOR BACK DOOR LOCK ASSY




- (a) Check operation of the door lock.
- (1) Using a screwdriver, push the latch in order to put the back door lock in the locked condition (full-latch position).
 - (2) Connect the positive (+) lead to terminal 1 and the negative (-) lead to terminal 2. Then, check operation of the latch.

Standard: The latch turns to the open-latch position

- (3) Inspect motor operation when battery voltage is applied to the terminals.

Standard:

Measurement Condition	Specified Condition
Battery positive (+) ⇔ Terminal 2 Battery negative (-) ⇔ Terminal 1	Clockwise☑Motor in normal rotation☑
Battery positive (+) ⇔ Terminal 1 Battery negative (-) ⇔ Terminal 2	Counterclockwise (Motor in reverse rotation)



- (b) Check the back door courtesy switch continuity.
- (1) Check the continuity between the terminals of the courtesy switch.

Standard:

Door Lock Latch Position	Terminal No.	Specified Condition
Open-latch position, Half-latch position	4 ↔ 5	Continuity
Full-latch position, Over-latch position	4 ↔ 5	No continuity

- (c) Check the back door latch switch continuity.
- (1) Check the continuity between the terminals of the latch switch.

Standard:

Door Lock Latch Position	Terminal No.	Specified Condition
Open-latch position, Over-latch position	4 ↔ 6	Continuity
Half-latch position, Full-latch position	4 ↔ 6	No continuity

- (d) Check the position switch continuity.
- (1) Connect the battery positive (+) lead to connector terminal 1 and the negative (-) lead to connector terminal 2.

Standard:

Door Lock Latch Position	Terminal No.	Specified Condition
Any position other than motor stop position (Motor in operation)	3 ↔ 4	Continuity
Motor stop position (Gear in original position)	3 ↔ 4	No continuity

NG**REPLACE W/MOTOR BACK DOOR LOCK ASSY****OK****REPLACE MULTIPLEX NETWORK DOOR ECU BACK**