

INSPECTION PROCEDURE

1 INSPECT COURTESY LAMP SWITCH(DRIVER SIDE DOOR)

(a) Inspect front door courtesy lamp switch continuity.

(1) Check that there is continuity between terminal 1 and body ground, when switch is operated.

Standard:

ON (When shaft is pressed): No continuity

OFF (When shaft is not pressed): Continuity

NG

REPLACE COURTESY LAMP SWITCH

OK

2 INSPECT DRIVE SIDE JUNCTION BLOCK(SIG)

(a) Insert the ignition key to the key cylinder.

(b) Measure the voltage between terminal 1C-2 of driver side junction block and body ground.

Standard:

Ignition key	Specified condition
Insert	10 - 14 V
Uninsert	Below 1V

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

CHECK AND REPLACE DRIVE SIDE JUNCTION BLOCK