


KEY INTER LOCK SOLENOID INSPECTION

40085-03



1. INSPECT KEY INTER LOCK SOLENOID

- (a) Disconnect the solenoid connector.
- (b) Connect KLS+ (4) terminal to the batteries' positive (+) terminal, and KLS- (3) terminal to the battery negative (-) terminal, and apply about 12V between KLS+ - KLS- terminals.

Check that operation noise can be heard from the solenoid.

If the solenoid does not operate, replace the solenoid.