



YAWRATE SENSOR REPLACEMENT

1. REMOVE CONSOLE UPPER REAR PANEL SUB-ASSY (See page 71-12)
2. REMOVE CONSOLE PANEL SUB-ASSY UPPER (See page 71-12)
3. REMOVE CONSOLE UPPER PANEL GARNISH NO.1 (See page 71-12)
4. REMOVE CONSOLE UPPER PANEL GARNISH NO.2 (See page 71-12)
5. REMOVE CONSOLE BOX ASSY REAR (See page 71-12)



6. REMOVE YAWRATE SENSOR

- (a) Disconnect the yawrate sensor connector.
- (b) Remove the 2 bolts and yawrate sensor.



7. INSTALL YAWRATE SENSOR

- (a) Install the yawrate sensor with 2 bolts.
Torque: 13.3 N·m (136 kgf·cm, 10 ft·lbf)
- (b) Connect the yawrate sensor connector.

8. INSTALL CONSOLE BOX ASSY REAR
9. INSTALL CONSOLE UPPER PANEL GARNISH NO.2
10. INSTALL CONSOLE UPPER PANEL GARNISH NO.1
11. INSTALL CONSOLE PANEL SUB-ASSY UPPER
12. INSTALL CONSOLE UPPER REAR PANEL SUB-ASSY
13. PERFORM YAWRATE SENSOR ZERO POINT CALIBRATION (See page 05-307)
14. CHECK VSC SENSOR SIGNAL (See page 05-307)