


DTC	C1268/68	TRANSFER L4 POSITION SWITCH CIRCUIT
-----	----------	-------------------------------------

## CIRCUIT DESCRIPTION


DTC No.	DTC Detecting Condition	Trouble Area
C1268 / 68	Open or short circuit in transfer L4 position switch circuit.	<ul style="list-style-type: none"> <li>Transfer L4 position switch</li> <li>Transfer L4 indicator switch circuit</li> </ul>

## WIRING DIAGRAM



C

F42919

**INSPECTION PROCEDURE****1 CHECK VOLTAGE(EXI4 OF SKID CONTROL ECU AND BODY GROUND)**

- (a) Remove the skid control ECU with the connectors still connected.
- (b) Turn the ignition switch ON.
- (c) Measure voltage between terminal EXI4 (V18 - 17) of the skid control ECU and body ground with the transfer shift lever in L4 position and in other than L4 position.

**OK:****Voltage:****L4 position: Below 2.0 V****Except L4 position: 10 - 14 V****OK****PROCEED TO NEXT CIRCUIT INSPECTION  
SHOWN IN PROBLEM SYMPTOMS TABLE****NG****2 CHECK TRANSFER L4 POSITION SWITCH****NG****REPAIR TRANSFER L4 POSITION SWITCH****OK****3 CHECK HARNESS AND CONNECTOR(4WD ECU - SKID CONTROL ECU)**

- (a) Check for open and short circuit in harness and connector between 4WD ECU and skid control ECU (See page [01-35](#) ).

**NG****REPAIR OR REPLACE HARNESS OR  
CONNECTOR****OK****CHECK AND REPLACE SKID CONTROL ECU ASSY**