


INSPECTION




1. INSPECT FRONT SEAT INNER BELT ASSY LH

- (a) Inspect the buckleswitch.
- (1) Fasten the seat belt (Buckleswitch is ON).
 - (2) Inspect the continuity and resistance between the terminals.

Standard:

Terminal No.	Specified condition
A-6 ↔ A-3	1,330 Ω
A-4 ↔ A-3	Continuity




- (3) Release the seat belt (Buckleswitch is OFF).
- (4) Inspect the continuity and resistance between the terminals.

Standard:

Terminal No.	Specified condition
A-6 ↔ A-3	330 Ω
A-4 ↔ A-3	No continuity

If the result is not as specified, replace the inner belt Assy.




- (b) Inspect the circuit for the airbag seat position sensor.
- (1) Inspect the continuity between connector A and the connector for the airbag seat position sensor.

Standard:

Terminal No.	Specified condition
A-2 ↔ 1 (Connector for airbag seat position sensor)	Continuity
A-1 ↔ 2 (Connector for airbag seat position sensor)	

If the result is not as specified, replace the inner belt Assy.




2. INSPECT FRONT SEAT INNER BELT ASSY RH

(a) Inspect the buckle switch.

- (1) Fasten the seat belt (Buckle switch is ON).
- (2) Inspect the continuity and resistance between the terminals.

Standard:

Terminal No.	Specified condition
A-2 ⇔ A-4	Continuity
A-1 ⇔ A-3	No continuity



(3) Release the seat belt (Buckle switch is OFF).

- (4) Inspect the continuity and resistance between the terminals.

Standard:

Terminal No.	Specified condition
A-1 ⇔ A-3	No continuity
A-2 ⇔ A-4	Continuity

If the result is not as specified, replace the inner belt assy.