

## PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See page
Engine does not crank (Does not start)	7. Cranking holding function circuit 8. Starter 9. Starter relay	<a href="#">05-233</a> <a href="#">19-1</a> <a href="#">19-1</a>
No initial combustion (Does not start)	1. ECM power source circuit 2. Fuel pump control circuit 3. ECM	<a href="#">05-228</a> <a href="#">05-241</a> <a href="#">01-35</a>
No complete combustion (Does not start)	1. Fuel pump control circuit	<a href="#">05-241</a>
Engine cranks normally (Difficult to start)	1. Starter signal circuit 2. Fuel pump control circuit 3. Compression	<a href="#">05-171</a> <a href="#">05-241</a> <a href="#">14-1</a>
Cold engine (Difficult to start)	1. Starter signal circuit 2. Fuel pump control circuit	<a href="#">05-171</a> <a href="#">05-241</a>
Hot engine (Difficult to start)	1. Starter signal circuit 2. Fuel pump control circuit	<a href="#">05-171</a> <a href="#">05-241</a>
High engine idle speed (Poor idling)	1. A/C signal circuit (Compressor circuit) 2. ECM power source circuit	<a href="#">05-328</a> <a href="#">05-228</a>
Low engine idle speed (Poor idling)	1. A/C signal circuit (Compressor circuit) 2. Fuel pump control circuit	<a href="#">05-328</a> <a href="#">05-241</a>
Rough idling (Poor idling)	1. Compression 2. Fuel pump control circuit	<a href="#">14-1</a> <a href="#">05-241</a>
Hunting (Poor idling)	1. ECM power source circuit 2. Fuel pump control circuit	<a href="#">05-228</a> <a href="#">05-241</a>
Hesitation/Poor acceleration (Poor driveability)	1. Fuel pump control circuit 2. A/T faulty	<a href="#">05-241</a> <a href="#">05-286</a>
Surging (Poor driveability)	1. Fuel pump control circuit	<a href="#">05-241</a>
Engine stalls soon after starting	1. Fuel pump control circuit	<a href="#">05-241</a>
Engine stalls during A/C operation	1. A/C signal circuit (Compressor circuit) 2. ECM	<a href="#">05-328</a> <a href="#">01-35</a>
Unable to refuel/Difficult to refuel	1. ORVR system	