


























# DIFFERENTIAL PREPARATION SST














0227B-01










	09223-00010	Cover & Seal Replacer	DIFFERENTIAL FRONT(1GR-FE	CARRIER (4WD))	ASSY
	09226-10010	Crankshaft Front & Rear Bearing Replacer	DIFFERENTIAL FRONT(1GR-FE	CARRIER (4WD))	ASSY
	09308-00010	Oil Seal Puller	DIFFERENTIAL FRONT(1GR-FE	CARRIER (4WD))	ASSY
	09308-10010	Oil Seal Puller	DIFFERENTIAL FRONT(1GR-FE	CARRIER (4WD))	ASSY
	09330-00021	Companion Flange Holding Tool	DIFFERENTIAL FRONT(1GR-FE	CARRIER (4WD))	ASSY
	(09330-00030)	Pin	DIFFERENTIAL FRONT(1GR-FE	CARRIER (4WD))	ASSY
	09350-20015	TOYOTA Automatic Transmission Tool Set	DIFFERENTIAL FRONT(1GR-FE	CARRIER (4WD))	ASSY
	(09369-20040)	Piston Spring Compressor Set	DIFFERENTIAL FRONT(1GR-FE	CARRIER (4WD))	ASSY
	09502-12010	Differential Bearing Replacer	DIFFERENTIAL FRONT(1GR-FE	CARRIER (4WD))	ASSY
	09506-30012	Differential Drive Pinion Rear Bearing Cone Replacer	DIFFERENTIAL FRONT(1GR-FE	CARRIER (4WD))	ASSY
	09554-22010	Differential Oil Seal Replacer	DIFFERENTIAL FRONT(1GR-FE	CARRIER (4WD))	ASSY
	09556-22010	Drive Pinion Front Bearing Remover	DIFFERENTIAL FRONT(1GR-FE	CARRIER (4WD))	ASSY

## PREPARATION - DIFFERENTIAL





	09564-3201 1	Differential Preload Adaptor	DIFFERENTIAL CARRIER ASSY FRONT(1GR-FE (4WD))
	09608-32010	Steering Knuckle Oil Seal Replacer	DIFFERENTIAL CARRIER ASSY FRONT(1GR-FE (4WD))
	09612-65014	Steering Worm Bearing Puller	DIFFERENTIAL CARRIER ASSY FRONT(1GR-FE (4WD))
	(09612-01020)	Claw "B"	DIFFERENTIAL CARRIER ASSY FRONT(1GR-FE (4WD))
	(09612-01050)	Hanger Pin with Nut	DIFFERENTIAL CARRIER ASSY FRONT(1GR-FE (4WD))
	09628-6201 1	Bolt Joint Puller	DIFFERENTIAL CARRIER ASSY FRONT(1GR-FE (4WD))
	09930-00010	Drive Shaft Nut Chisel	DIFFERENTIAL CARRIER ASSY FRONT(1GR-FE (4WD))
	09950-00020	Bearing Remover	DIFFERENTIAL CARRIER ASSY FRONT(1GR-FE (4WD))
	(09951-00680)	Replacer 68	DIFFERENTIAL CARRIER ASSY FRONT(1GR-FE (4WD))
	(09951-00890)	Replacer 89	DIFFERENTIAL CARRIER ASSY FRONT(1GR-FE (4WD))
	09950-30012	Puller A Set	DIFFERENTIAL CARRIER ASSY FRONT(1GR-FE (4WD))
	(09951-03010)	Upper Plate	DIFFERENTIAL CARRIER ASSY FRONT(1GR-FE (4WD))
	(09953-03010)	Center Bolt	DIFFERENTIAL CARRIER ASSY FRONT(1GR-FE (4WD))

## PREPARATION - DIFFERENTIAL

	(09954-03010) Arm	DIFFERENTIAL CARRIER ASSY FRONT(1GR-FE (4WD))
	(09955-03030) Lower Plate 130	DIFFERENTIAL CARRIER ASSY FRONT(1GR-FE (4WD))
	(09956-03020) Adapter 18	DIFFERENTIAL CARRIER ASSY FRONT(1GR-FE (4WD))
	09950-4001 1 Puller B Set	DIFFERENTIAL CARRIER ASSY FRONT(1GR-FE (4WD))
	(09951-04010) Hanger 150	DIFFERENTIAL CARRIER ASSY FRONT(1GR-FE (4WD))
	(09951-04020) Hanger 200	DIFFERENTIAL CARRIER ASSY FRONT(1GR-FE (4WD))
	(09952-04010) Slide Arm	DIFFERENTIAL CARRIER ASSY FRONT(1GR-FE (4WD))
	(09953-04020) Center Bolt 150	DIFFERENTIAL CARRIER ASSY FRONT(1GR-FE (4WD))
	(09953-04030) Center Bolt 200	DIFFERENTIAL CARRIER ASSY FRONT(1GR-FE (4WD))
	(09954-04010) Arm 25	DIFFERENTIAL CARRIER ASSY FRONT(1GR-FE (4WD))
	(09955-0401 1) Claw No.1	DIFFERENTIAL CARRIER ASSY FRONT(1GR-FE (4WD))
	(09955-04061) Claw No.6	DIFFERENTIAL CARRIER ASSY FRONT(1GR-FE (4WD))
	(09957-04010) Attachment	DIFFERENTIAL CARRIER ASSY FRONT(1GR-FE (4WD))

	(09958-0401 1) Holder	DIFFERENTIAL CARRIER ASSY FRONT(1GR-FE (4WD))
	09950-60010 Replacer Set	DIFFERENTIAL CARRIER ASSY FRONT(1GR-FE (4WD))
	(09951-00380) Replacer 38	DIFFERENTIAL CARRIER ASSY FRONT(1GR-FE (4WD))
	(09951-00390) Replacer 39	DIFFERENTIAL CARRIER ASSY FRONT(1GR-FE (4WD))
	09950-60020 Replacer Set No.2	DIFFERENTIAL CARRIER ASSY FRONT(1GR-FE (4WD))
	(09951-00680) Replacer 68	DIFFERENTIAL CARRIER ASSY FRONT(1GR-FE (4WD))
	(09951-00810) Replacer 81	DIFFERENTIAL CARRIER ASSY FRONT(1GR-FE (4WD))
	09950-70010 Handle Set	DIFFERENTIAL CARRIER ASSY FRONT(1GR-FE (4WD))
	(09951-07150) Handle 150	DIFFERENTIAL CARRIER ASSY FRONT(1GR-FE (4WD))

### Recommended Tools

	09011-12301 Socket Wrench 30 mm	DIFFERENTIAL CARRIER ASSY FRONT(1GR-FE (4WD))
	09031-00030 Pin Punch	DIFFERENTIAL CARRIER ASSY FRONT(1GR-FE (4WD))
	09905-00012 Snap Ring No.1 Expander	DIFFERENTIAL CARRIER ASSY FRONT(1GR-FE (4WD))
	09905-00013 Snap Ring Pliers	DIFFERENTIAL CARRIER ASSY FRONT(1GR-FE (4WD))

**Equipment**

Dial indicator	
Micrometer	
Torque wrench	
Vernier calipers	
Press	