


CAM POSITION SENSOR ASSY (2UZ-FE)

1805F-01

REPLACEMENT

1. DRAIN ENGINE COOLANT (See page 16-5)
2. REMOVE FAN AND GENERATOR V BELT (See page 14-5)
3. REMOVE OIL COOLER PIPE (See page 14-107)
4. REMOVE TIMING BELT COVER SUB-ASSY N0.3 LH (See page 14-107)



5. REMOVE CAM POSITION SENSOR ASSY
 - (a) Remove the bolt, stud bolt and cam position sensor.

6. INSTALL CAM POSITION SENSOR ASSY
 - (a) Install the cam position sensor with bolt and stud bolt.
Torque: 7.5 N·m (76 kgf·cm, 66 in·lbf)
7. INSTALL TIMING BELT COVER SUB-ASSY N0.3 LH (See page 14-107)
8. INSTALL OIL COOLER PIPE (See page 14-107)
9. INSTALL FAN AND GENERATOR V BELT (See page 14-5)
10. REFILL ENGINE COOLANT (See page 16-5)
11. CHECK FOR ENGINE COOLANT LEAKS(See page 16-1)