

SEAT BELT WARNING SYSTEM LOCATION

610AU-01

Combination Meter (Driver Side Seat Belt Warning Lamp)

Passenger Side Seat Belt Warning Lamp Assy

Seat Belt Warning Sensor
(Built in Passenger Side Seat)

Front Seat Inner Belt Assy LH

Front Seat Inner Belt Assy RH

P

B64689